

In order to replace the battery on a Volkswagon Key you first need to disassemble your key. This takes a bit more force than most people are willing to do, for fear of breaking it.


Battery Type: CR2032



Step 1 is basically grab the key from both ends and pull hard.



The key will separate into two halves.



Step 2 is the harder part. Pull from the front or side and it should pop open.



Here you can see where the two pieces separate.



Fully separated.



The rest is pretty simple. To replace the battery, do it in reverse order. Each piece goes back together normally.

[Back](#)